

---

Region	Dat-18	Arpt	IDENT	Airport Name	Latitude	Longitude	Rnwys
AFR	U		FAFB	FICKSBURG SENTRAOES	S28493000	E027543000	0
AFR	U		FAKD	P.C. PELSER	S26520000	E026430000	0
AFR	U		FAMI	MARBLE HALL	S24593000	E029170000	0
AFR	U		FAQT	QUEENSTOWN	S31550000	E026530000	0
AFR	U		FARS	ROBERTSON	S33483900	E019543600	0
AFR	U		FASB	SPRINGBOK	S29412200	E017562000	0
AFR	U		FASC	SECUNDA	S26311400	E029102000	2
AFR	U		FASD	SALDANAHA-VREDENBURG	S32574800	E017581200	0
AFR	U		FASH	STELLENBOSCH	S33585000	E018492200	0
AFR	U		FASI	SPRINGS	S26150000	E028240000	0
AFR	U		FASX	HENDRIK SWELLENGREBEL	S34030000	E020290000	0
AFR	U		FBJW	JWANENG	S24360000	E024400000	0
AFR	U		FBOR	ORAPA	S21160000	E025190000	0
AFR	U		FNCP	CAPANDA	S09460700	E015271600	2
AFR	U		FNCV	CUITO CUANAVALA	S15093600	E019092520	2
AFR	U		FNMA	MALANGE	S09311038	E016181434	2
AFR	U		FNUG	UIGE	S07361000	E015014000	2
AFR	U		FOGQ	OKONDJA	S00395100	E013402200	0
AFR	U		FOOH	OMBOUE HOSPITAL	S01350000	E009160000	0
AFR	U		FQBI	BILENE	S25160000	E033140000	0
AFR	U		FQPO	PONTA DE OURO	S26500000	E032500000	0
AFR	U		FXMK	MOKHOTLONG	S29165000	E029042000	0
AFR	U		FXMU	MEJAMETALANA AB	S29181000	E027301000	0
AFR	U		FXQN	QACHA 'S NEK	S30064000	E028402000	0
AFR	U		FXSM	SEMONKONG	S29502000	E028033000	0
AFR	U		FYAR	ARANDIS	S22280000	E014590000	0
AFR	U		FYGF	GROOTFONTEIN	S19360000	E018080000	0
AFR	U		FZAG	MUANDA	S05560000	E012210000	0
AFR	U		FZKJ	BUTA-ZEGA	N02490000	E024470000	0
AFR	U		GFBN	BONTHE	N07315900	W012301400	0
AFR	U		HE01	EL GOUNA	N27220100	E033400500	0
AFR	U		HRYI	BUTARE	S02360000	E029440000	0
AFR	U		HUKK	KAKIRA	N00300000	E033164800	0
EEU	U		UEST	TIKSI	N71414400	E128540200	2
EEU	U		UHWE	YEDINKA	N47104800	E138385400	2
EEU	U		UNNE	YELTSOVKA	N55053000	E083001400	2
EEU	U		UTDD	DUSHANBE	N38323700	E068492900	2
EEU	U		UTDT	BOKHTAR	N37520200	E068515200	2
MES	U		VOAR	ARKONAM	N13040000	E079410000	2
PAC	U		PLPA	PALMYRA	N05530000	W162040000	0
SAM	U		SGST	SANTA TERESA	S22372400	W056380600	0